

In order for the Curtain Baskets to operate smoothly, begin by positioning the Gearbox Crank Arm so that it is in the vertical position as shown. For proper adjustment position a torpedo level on the Crank Arm and Basket Arm as shown to ensure an EXACT horizontal level is achieved as shown. Adjust the Basket Arm position by twisting the T bolt bushing connected to the Crank Rod by either shortening or lengthening the Crank Rod until this vertical positions are achieved.

The Crank Arm and the Basket Arm MUST be adjusted so that they are PARALLEL with each other. Operate curtain for 15 minutes and check for smooth operation. Repeat the steps if smooth operation is not achieved.

For customer service, please call: 718-585-6463 or Toll Free: 800-344-5154



Crank Arm Adjustment

Date: 03/26/2003 Version #1